



AEROMATIC™ SERIES HRV/ERV HRV/ERV Controls

For Aeromatic™ Series Standard Residential,
Multi-Family, and Light Commercial HRV/ERV Models

PRODUCT
SPECIFICATIONS
& TECHNICAL
DATA

Controls for Aeromatic™ Series Standard Residential, Multi-Family, and Light Commercial HRV/ERV models allow you to easily activate a variety of functions at the touch of a button. Each control requires low-voltage (24 VAC) power and fits inside any 2" x 4" service box. All controls include retaining screws and a white deco wall plate.

Humidity Control (P/N 611224)



- Activates the HRV/ERV to remove excess humidity as desired; the unit returns to its default operation mode when desired humidity is reached
- Indicates the moisture content (%RH) of the ambient air

LCD Multifunction Control (P/N 611227)



- Easy-to-read liquid-crystal display (LCD) shows ambient temperature, relative humidity setpoint, actual relative humidity, and operating mode
- Equipped with humidity sensor to keep the relative humidity (%RH) at or below the desired setting
- Activates HRV/ERV high-speed mode when there is excess humidity; defaults to pre-set operation mode when desired humidity level is reached

20/40/60 Minute Timer (P/N 611228)



- Activates the HRV/ERV to operate on high-speed mode for 20, 40, or 60 minutes

Speed Control (P/N 611229)



- 4 HRV/ERV speeds:
 - » Intermittent mode (successive cycles, low-speed 20-minute exchange, 40-minute stop mode)
 - » Low-speed exterior exchange mode
 - » High-speed exterior exchange mode
 - » Unit stop mode

Mode Control (P/N 611230)



- 4 modes of HRV/ERV operation:
 - » Recirculation mode
 - » Low-speed exterior exchange mode
 - » High-speed exterior exchange mode
 - » Unit stop mode
- Not compatible with H110-TF and E110-TF

© 2014 American ALDES Ventilation Corporation. Reproduction or distribution, in whole or in part, of this document, in any form or by any means, without the express written consent of American ALDES Ventilation Corporation, is strictly prohibited. The information contained within this document is subject to change without prior written notice.

American ALDES Ventilation Corporation • 4521 19th Street Court East, Suite 104 • Bradenton, FL 34203 – USA
941.351.3441 • 800.255.7749 • 941.351.3442 (fax) • info@americanaldes.com • www.aldes.us