




## DORMER VENTS MODEL # DV2011-R



Under Eave/Soffit Vents	Model	Size W x H	NFVA Provided	Flanges Available	Flange Definition	Weight
	DV2011-R	9"x 18"	56	Standard	As Shown	4lbs
CUSTOM SIZES and materials AVAILABLE						

### BENEFITS:

- Safety vents that are used in areas prone to wildfires, wind driven rain, or winddriven snow.
- Overlapping Baffle Protection (Patented)
  - Air Flows through normally
  - Resists the intrusion of Flame and Embers, Wind Driven Rain and Wind Driven Snow
- WUI Compliant and with California Ch7a Building Code
- Anti -Clogging Overlapping Baffles plus 1/8" mesh on back side of vent
- Passed Miami Dade Driving Rain Test @ 140mph with no rain penetration
- Prevents Rodent Entry
- 20 Year FULL Warranty
- Easy to Install, Retrofit and Paint

### STANDARD MATERIALS

ASTM A653/A653M- G90 hot dipped galvanized steel, 26GA  
 ASTM D9092- mill phosphatized coating for painting. IF BONDERIZED  
 ASTM b370- Sheet Copper, 16oz and 20oz IF GALVANIZED  
 .025 x.025 hot dipped galvanized 23ga wire mesh

## Installation:

- 1) Cut and remove existing horizontal louvers on existing Dormer Vent.
- 2) Place ample amounts of exterior fire rated sealant behind 3" curved top flange of Dormer Retrofit.
- 3) Place Dormer Retrofit tightly over existing opening of old dormer vent. 3" curved top flange should go over the top of the existing dormer vent.
- 4) Secure with tapping screws 2" apart all along the entire 3" curved top flange.

NOTE: Always check local building codes for required NFVA/airflow minimums for attic spaces to ensure your retrofit meets code.